

CARGO COMPARTMENT LOADING LIMITS

The center of gravity for any given quantity of cargo must be located between the corresponding forward and aft limit curves as indicated.